PARTS LIST - RD-1C

You should find the following parts in the shipping container of the RD-1C

1. Main Gear housing with propeller shaft installed. (First 5 items will be bolted together on the shipping skid with two bolts, washers & nuts)
2. Gear housing spacer
3. Ring Gear
4. Planet Gear assembly with thrust bearing
5. Ring gear retainer O-ring, 5.125" OD, x .190" thick
6. Nylon snubber/spacer (To be Installed on propeller shaft between sun gear and planet gear assembly)
7. Input shaft and sun gear with thrust bearing (packed along with nylon snubber/spacer above)
8. Adapter plate with oil seal installed. (unless ordered without adapter plate)
9. 4 Adapter plate spacers "
10. 12 AN4 -47A bolts (including two used to bolt gear housing to shipping skid)
11. 12 AN4 -365 elastic stop nuts
12. Damper plate (aluminum) with input shaft spline drive.
13. 4 Damper drive lugs (steel)
14. 4 Rubber dampers (1.375" OD x .75" ID) (items 12,13 & 14 are furnished pre-assembled)
15. 4 AN7-14A damper bolts
16. 8 AN7 washers (large)
17. 4 AN7 washers (small)
18. 4 7/16" ID thick washers
19. 24 ¼" washers
20. 4 120mm long 10mm dia. Bolts (Unless ordered without)
21. 2 110mm long 10mm dia bolts "
22. 8 10mm washers "
23. 4 10mm nuts "
24. Instructions (this document)